
EDMS v3.0


User's Manual

Contents


1. Install the USB driver.....	1
2. Install the EDMS software.....	4
3. EDMS user's guide.....	6
4. USB driver installation error solution.....	13

1. Install the USB driver


1.1 If you first time use the gauge, when you connect the gauge to the PC, it will come out a driver installation window.




1.2 Select the USB driver path, it was in the CD




1.3 Click next




1.4 Check the driver




1.5 select continue anyway



1.6 Install



1.7 Install the driver successfully




2. Install the EDMS software


2.1 Double click the EDMS.exe




2.2 Click next




2.3 Set up the installation path and the click next




2.4 Click next




2.5 Click next



2.6 Install



2.7 Finish install




3. EDMS user's guide


3.1 Connect to PC

Connect the USB cable to force gauge, and connect them to PC.



The USB driver for this software should be installed at the first time. The driver software is included in CD.





3.2 Open the software




Connect gauge to PC, turn on the gauge. Open EDMS by double click the software icon.


EDMS can identify connection with gauge automatically. If the connection is all right,  icon will be showed, otherwise will show .

If  is showing, means the connection is not normal, you can click  button for trying to connect manually. If you still can not connect, the message "Can not find the device please reconnect the device or power on the device".


So check the USB cable, or the power of gauge. Or maybe you need to install USB driver.




3.3 Click the “Start acquisition” button. And then the software will draw the graph



3.4 Click the “Stop acquisition” and then it will show all data’s and the whole graphics




3.5 If you select the “upload memory mode”, it will upload the gauge memory data to the PC



3.6 Function

3.6.1 Select the upload way



Draw Graph

Choose the real time way, you can draw the graph by software.

Upload Memory

Choose the upload memory way, you can upload the gauge memory from this way

3.6.2 Control Area



You had connected the gauge



The gauge was not connect to the PC

3.6.3 Start acquisition

When the gauge was connected to the software, Click the “Start acquisition” button, the software will be running.

3.6.4 Export Data

Export the upload data.

3.6.5 Export Image

Export the image

3.6.6 Help

Open the help file

3.6.7 Setting



The screenshot shows a software settings window with two tabs: 'Setting' and 'Advance'. The 'Setting' tab is active and contains the following controls: 'Report Name' (text box with 'test'), 'Readings per Seconds' (spin box with '10'), 'Load' (checkbox, unchecked, with a unit dropdown showing 'kgf'), 'Show grid' (checkbox, checked), and 'Invert Load' (checkbox, unchecked). The 'Advance' tab is also visible and contains: two graph icons, 'g' (spin box with '9.807'), 'Range of Avg.' (spin box with '0'), 'Range of Peak' (spin box with '0'), and a 'Calculate' button.

Report Name:

Set the name of the current data

Readings per Seconds

This numeric box sets the number of readings per second that Software requests data from the gauge and the available range is 0 to 60 readings per second.

Load

You can change the load unit,.

Show gird

Display or not display the gird

Invert Load

Invert the load direction

Advance



Set a zoom window with adjustable x- and y- dimensions for a specific part of the graph



View entire graph

G

Set the gravity acceleration value

Calculate

Get the range of average and the Peak value

3.6.8 Test setup

The screenshot shows a 'Test Setup' dialog box with the following controls:

- Start Condition:**
 - ☒ Time: Delay to start [0]
 - ☐ Load: Threshold [0]
- Stop Condition:**
 - ☒ Time: [100]
 - ☐ Load: Threshold [100]
- ☐ Break Detect: [80] % of Maximum

Start Condition

Select an option button for time delay, load threshold to begin the test.

Time

Set time delay, in seconds, to begin the test.

Load

Set a load threshold to begin the test

Stop Condition

Select an option button for time, load to stop the test.

Time

Set the duration of the test, in seconds.

Load

Set the load threshold at which to terminate the test

Break Detect

Stop the test when the load decreases to a specified percentage of the maximum (peak) reading during the test.

3.7 Status bar



You can through the status bar to check the current software working condition

1. Connected or Not Connect

If the gauge connect to the PC, when you open the software, it showed Connected or showed Not Connected

2. Ready or Running

It showed “Ready”, the software is not working, and when it showed “Running”, it means


the software is working

3. The current version number

4. The running time


3.8 Error Message

1



You should connect the gauge or power on the gauge.

2.



When the software is connecting to the gauge, you should not take the USB Port out, if it came out the message, you should reconnect the USB port.

3.


Element not found!

Copy the "Ntgraph.ocx" file to C:\WINDOWS\system32: cover the old files


4. USB driver installation error solution

4.1 If the USB driver was installed error, you can manually install the USB driver by steps


Step1: right button click my computer, select the properties



Step2. Click the Hardware



Step3: Check the port (COM &LPT)



If you found the JM CDC DEMO, it means the USB driver was not installed successfully

Step4: Right button click and then select Update Driver, then you can install the driver (see **Install the USB driver**)

