



USB to Serial Converter – User Manual

Driver Installation

1. Open the driver, choose your operating system, double clicks to proceed. The driver installation wizard will guide you to complete the process.



2. After installing the driver, open Device Manager and check the installation status. As picture below, it means that the driver installation is successful.



Serial Communication Setting

After installing, you can do setting for serial port according to your requirement on serial communication. Make sure that the setting is correct and matching, otherwise, the computer and devices will not work correctly. For example, some industrial equipments supporting the application software, you need to specify the corresponding port for communication. Please refer to the illustration as below (right click on “USB Serial Port (COM)”) for setting.

